DECO MESH

TP-Link Deco M4 Mesh System setup

Manual





Scan the QR code to visit our website

TP-Link Deco M4 Mesh System setup Manual

- Take one Deco the one you want to act as the main router. Plug an Ethernet cable from your modem into the Deco's WAN/LAN port.
- Power on the Deco. Wait for the LED to start blinking blue. That means it's ready to be set up.
- Install the Deco app from the App Store or Google Play. It's by TP-Link — make sure it's the legit one. Open it. Make an account if you haven't already.



OR








- Open up the Deco app. It's going to ask what model you've got –
 pick Deco M4.
- Follow the prompts. It's going to scan for the Deco unit usually finds it pretty quick if your phone's Bluetooth and location are on.
- Once it finds it, you'll name your network and slap a password on it. Standard stuff. No need to overthink SSID names unless you want to be That Guy with "FBI Surveillance Van" or whatever.

- Plug in the second and third units wherever. Don't even worry about Ethernet. Just power them up.
- The app will guide you through adding each one same deal, wait for blue pulse light, hit "Add another Deco," rinse and repeat.



- Once they're all added, the app will say something like "Network is online."
- Walk around your house and test signal strength most phones will show you Wi-Fi handoffs between nodes.



THANK YOU

CALL NOW

888-762-7719

support@deco-mesh.net



Scan the QR code to visit our website